

This Guide offers step-by-step instructions for quick, hassle-free installation of TRUEGRID® ROOT™ Permeable Paving. If you have any questions about your installation, please contact a TRUEGRID Installation Specialist at 855-355-GRID (855-355-4743)

## Before you begin: Materials & Equipment

### *Materials checklist*

\_\_\_ TRUEGRID PRO ROOT™ Pavers

### *Equipment checklist*

\_\_\_ Compaction equipment: to compress TRUEGRID ROOT™ into existing grass.

Example: Heavy roller or plate compactor for smaller areas. Heavy roller is quickest for large areas.

\_\_\_ circular saw or reciprocating saw (if needed for trimming edges or around existing objects/trees on lot)

## Before you begin: Site Prep

1. Level out any deep potholes or ruts, if needed. TRUEGRID ROOT™ will flex to conform to most surface unevenness that exist.

- Fill in and compact infill for any existing ruts or pot holes in the lot.
- Ground is best to be damp for a softer grass surface before compressing TRUEGRID ROOT™ into place.

## Installation steps

1. Install TRUEGRID ROOT™

- Start in corner of site with female tabs on grid facing out. Line up grid and connect next grid section with empty cells facing down. TRUEGRID ROOT™ w/the most surface area should be facing up. TRUEGRID will typically go down at around 1000 SF per man/hr.

2. Compress TRUEGRID ROOT™ into damp grass surface w/heavy roller or other equipment.

3. TRUEGRID ROOT™ can be trimmed to fit around trees or any other existing objects that need to remain on grass lot TRUEGRID ROOT™ can be trimmed to fit along parking lot edges, if needed.